






### 4b Multichannel - Loewe wireless digital audiolink




Multichannel  
Loewe wireless digital audiolink  
Setup Video



### Pairing multi.room amp



### 4c TV mode - HDMI ARC



Loewe multi.room amp  
Online Manual




Loewe Technology GmbH,  
Customer Care Center  
Industriestraße 11  
96317 Kronach, Deutschland  
Tel +49 9261 99-500  
Fax +49 9261 99-515  
E-mail: ccc@loewe.de  
Designed in Germany  
Printed in China  
Edition 1, 05.23 SB, MCM



Änderungen vorbehalten  
Subject to modifications  
Onder voorbehoud van wijzigingen  
Sous réserve de modifications  
Soggetto a modifichie  
Con sujeción a modificaciones  
Sujeito a alterações  
Mo e podlega modyfikacjom  
Zm ny vyhrazeny  
Zmeny vyhradené  
Var tikt main ts  
Gali keistis  
Toodet võidakse muuta  
Med förbehold for ændringer  
Med förbehåll för ändringar  
Oikeus muutoksiin pidätetään  
Kan endres  
Podložno izmjenama  
Predmet sprememb  
Sub rezerva modific rilor  
Υπόκειται σε τροποποιήσεις  
Возможно внесение изменений  
Компанія залишає за собою право вносити зміни

# Loewe **multi.room amp**

Quick Installation Guide




### Scope of delivery



HDMI ARC cable



CR2032





AC 220 - 240V



Please read safety instructions before using any electronics!



- Safety Instructions
- Technical Data
- Quick Installation Guide

### Overview




### Quick start


#### 1 Connect speaker




#### 2 Connect power cable




AC 220 - 240V



#### 3 Start device



#### Choose operation mode



#### 4a Multiroom - DTS Play-Fi

